



KIPFold 1800 User Guide Ver 1.1



Safety

Read these safety instructions completely before operating the folder and keep this manual for future reference close to the folder. Carefully observe all warnings, precautions and instructions on the folder or the ones described in the operating instructions. In order to guarantee hazard-free operations all maintenance and repairs are only to be carried out by trained personnel.

WARNING: Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.	Warning
CAUTION: Indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.	CAUTION

Maintenance and Modifications

To avoid the risk of introducing hazards, all modifications and maintenance activities are strictly reserved to properly qualified and trained service technicians. In daily use, any electrical equipment may be subject to parts wear and eventual failure. In order to maintain safety and reliability, the Customer Engineer (hereafter called CE) must perform regular maintenance inspections.	
--	--

General

ke sure that the folder is placed on a level, horizontal surface of sufficient strength. See the pective specifications sheet for the weight of the equipment vays use materials for the respective folder. Materials not approved can cause faults in the der. not use the folder when it is emitting unusual sounds. Remove the plug from the power cket or turn off the fixed connection to the electricity grid and contact Customer Service. not use the folder in rooms which are subject to excessive vibration. ve the folder careful and slow using two persons. t the adjustable feet on the ground when the folder is in the desired position	<u>^</u>
--	----------



Main connection cable

Do not use different connector cables, other than supplied with the folder. When replacement of the power supply cable is required because of damage or defect, contact your CE for proper replacement of this power supply cable.



Mains connection

Do not use an extension cable to connect the machine. This machine is not designed for connection to an IT power supply system. An IT power system is voltage network in which the neutral wire is not connected to earth. When the machine is connected through a wall-socket, place the machine near a wall-socket that is easily accessible. When the machine is connected through a fixed connection to the electricity grid, the disconnect device in the fixed connection must be easily accessible. The machine must be connected to an earth (grounded) outlet.	
--	--

Measures to take in case of an accident


 If an accident has occurred, the distributor who has been notified first must immediately take emergency measures to provide relief to affected persons and to prevent further damage. If a report of a serious accident has been received from a customer, an onsite evaluation must be carried out quickly by an authorised person. To determine the cause of the accident, conditions and materials must be recorded through direct on-site checks, in accordance with instructions. For reports and measures concerning serious accidents, follow the regulations specified by the distributor. 	Important
--	-----------

Disclaimer


These safeguards have been compiled to the best of our knowledge. They are intended as a compact guide to the safe handling of the product. We reserve the right to revise specification data sheets, as new information becomes available. It is the user's responsibility to determine the suitability of this information for the adoption of safety precautions as may be necessary. It is the user's responsibility to ensure that the specification data sheets are the latest ones issued. If and in so far as limitation of liability is permitted under the applicable laws, we do not accept liability for any inaccuracy that may occur in this information.



Machine Dimensions (Metric)




- 1. 1019mm (shipment height)
- 2. 899mm 1040mm (no riser), 1119mm 1260mm (220mm riser)
- 3. 665mm 806mm (no riser), 885mm 1026mm (220mm riser)
- 4. 1778mm
- 5. 26mm 126mm (depending on the angle of the tablet)



- 1. 1465mm
- 2. 852mm
- 3. 727mm




Conveyor tray extension




- 1. 43mm
- 2. 69mm



Machine Dimensions (Inch)




- 1.
- 2. 3.
- 40.12" (shipment height) 35.39" 40.94" (no riser), 44.06" 49.61" (8.66" riser) 26.18" 31.73" (no riser), 34.84" 40.39" (8.66" riser)
- 4. 70"
- 5. 1.02" - 4.96" (depending on the angle of the tablet)



- 1. 57.68"
- 2. 33.54"
- 3. 28.62"



Conveyor tray extension



1. 1.69"

2. 2.7"



Machine Specifications (Metric)

Cross Fold Tray	80 mixed documents at 80gr/sqm
Performance	• 20 A0 at 80/sqm
Min. document length	 210mm as unfolded cover sheet 420mm to be folded
Max. document length Fan fold only	28 layers with 80 gsm paperabsolute document length depends
	on panel width
	(approx. 28 x panel width)
Max document length Fan and cross fold	12 layers with 80gsm paper17 layers with stacking capacity
	limited to 3 packages
	absolute document length depends
	on panel width (approx. 12 x panel width)
Min. document width Max. document width	• 279mm
	• 914mm
Paper weight	• 60g/m ² - 110g/m ²
best quality with	• 75g/m² - 80g/m²
Panel width fan folder	• 170 - 230mm
Panel width cross fold Margin	 250 - 320mm 0 - 40mm
waigin	• 0 - 40mm
Folding speed	• 2,5 - 10m/min
Fold programs	• 255 – editable
Temperature	• 15°C - 35°C
Humidity	• 20% - 80%
Power supply	• 100V – 120V 50/60Hz
	• 200V – 240V 50/60Hz
Main Fuse	• 10A
Consumption standby	• 50W
Consumption max.	• 400W
Weight	• 332kg




Machine Specifications (Inch)

Cross Fold Tray Performance	80 mixed documents at 20lb20 E-size at 20lb
Min. document length	 8.5" or 9" as cover sheet 16.5 to be folded
Max. document length Fan fold only	 28 layers with 20lb paper absolute document length depends on panel width (approx. 28 x panel width)
Max document length Fan and cross fold	 12 layers with 20lb paper 17 layers with stacking capacity limited to 3 packages absolute document length depends on panel width (approx. 12 x panel width)
Min. document width Max. document width	• 11" • 36"
Paper weight best quality with	 16lb - 30lb 20lb - 24lb
Panel width fan folder Panel width cross fold Margin	 6.70" - 9.00" 10.00" - 12.0 0" 0" - 1.1/2"
Folding speed	• 8.2 - 32.8 ft/min
Fold programs	• 255 – editable
Temperature	• 59°F - 95°F
Humidity	• 20% - 80%
Power supply	 100V – 120V 50/60Hz 200V – 240V 50/60Hz
Main Fuse	• 10A
Consumption standby Consumption max.	 50W 400W
Weight	• 732lb



Power & Switch On




- The power supply box is at the folder's right bottom side.
- The main switch of the machine is next to the power cable connector.
- Find the folders serial number on the rating plate next to the switch.
- The machine can be completely switched off by disconnecting the power cable.
 - o This area must be accessible at all times






Basic Screens on the Folder





Main Folder Screen – Offline Mode



KIP	Shows the contact information of the technical service
O	Program editor / Service Mode
DIN B 210x297	Opens a list of available folding programs.

No part of this publication may be copied, reproduced or distributed in any form without express written permission from KIP.




Media and formats

Format limits		
Fan Folder	All documents with length from 210 mm (8.5") up to 6.000 mm (19,6 ft) (80 gr. Paper) or unlimited length (option) and width up to max. 914 mm (36").	
Cross FolderMaximum paper length of 2500 mm. Longer copies will not be transported into the cross folder but deployed fan folded off to the left side of the folder.		
Recommended n	nedia	
The paper weight should not be less than 60 g/m ² (18#) and not more than 110 g/m ² .(24#)		
For application media types, please contact your dealer.		
Film or materials with glossy shiny surfaces are not suitable.		



Select and customise programs



No part of this publication may be copied, reproduced or distributed in any form without express written permission from KIP.




Online Folding



In most cases the title block (legend) has to be on the leading edge of the document entering the folder. The title block position has to be set in the KIP software you are using.

If the printer reports the size of the copy, it is possible to print A1 and A2 (C-size and D-size) in landscape orientation. In this case the title block has to be at the leading edge for A1 or D-size and on the trailing edge for A2 or C-size





Using the KIPFold 1800 with KIP Print Management Suite

KIP System K applications allow either the selection of a folder preset packet and/or the creation of customised folder presets

KIP Applications/Function:

- KIP PrintPro Creation & Selection
 KIP PrintPro.Net Creation & Selection
 KIP Windows Driver Selection Only
- KIP AutoCAD Driver Selection Only

KIP ImagePro and Folding

Folder Preset Creation

Component	Function
1. System Preset Setup	System Preset Setup Image: Print Quality Presets Image: Scan Quality Presets Image: Stamp Presets



To create a folding Preset follow these steps.

Step	Action	Illustration
1.	Select the Folding Presets button from the Printer Information page.	Folding Presets Edit Folding Presets.
2.	Select the New Button	So New
3.	Name – This is the name that will be displayed in the Preset list of names and will be displayed on the main screen.	Name: 9x12 No Border
4.	Use Title Block Recognition – Checking this box enables Auto Title Block Recognition/Location.	FoldingTable: Use title block recognition



Step	Action	Illustration	
5.	Folding Table – This area is where all settings for the Fold Parameters are made.	1 2 3 4 5 6 7 8 9 10 11 12	
	The Folding Table Icon Explained:		
	1. Media Width		
	2. Fold Packet		
	3. Title Block Location (Used	when Title Block Recognition is checked)	
	4. Alignment – Used to shift the image Left, Centre, Right when the image is smaller than the paper size.		
	5. Rotation – For Portrait View		
	6. Rotation – For Landscape	/iew	
	7. Minimum Width / Short Ec	dge (see note)	
	8. Maximum Width / Short Ed	dge (see note)	
	9. Minimum Length/ long Edg	ge (see note)	
	10. Maximum Length / Long E	dge (see note)	
	11. Snap to Cut Length – Add b	plank paper to the trailing edge of the copy.	
	12. Inter Copy Delay – in tenth of a second for fast printers or when tab applicator option is used.		
	software knows what size the dra	configures the Minimum & Maximum for X&Y so that the wing is and what roll size/fold length/inter-copy delay are applied.	



Step	Action	illustration
6.	Media Width – Select the desired Media Width to be used.	Name: 9x12 No Border FoldingTable: Use title block recognition
7.	Fold Packet – Allows for the selection of the fold packet to be used.	Name: 9x12No Border Folding Table Ite title klock recognition Ite title klock recognition Ite title klock recognition 9 86 106 Top right Right No Rotation 270* 00127 Margin 0007* 0027 Margin 9:0021 Margin 9:0021 Margin 9:0021 Landscape 9:0021 Landscape
8.	Title Block Location – Allows for the selection of the title block Location. Note: when Use title block recognition is selected it is necessary to indicate where you want the title block to be.	Name: 9/12 No Border Folding Table: Use title block recognition Use title block recognition 0 36' 9.0/12 Top: 1 Right: No Rotation 270' 0.00' 0.00' 9 Bottom light Top: 1 Right: No Rotation 270' 0.00' 0.00' 9 Bottom light Top light Top light Top light 0

No part of this publication may be copied, reproduced or distributed in any form without express written permission from KIP.



9.	Alignment – Allows for the selection of Left, Right or Centre for alignment.	Name: 9x12 No Border Folding Table Ite to the block recognition Off Ite Ite </th
10.	Rotation for Portrait – allows for the setting of a rotation for Portrait documents.	Name: 9x12 ho Border FoldingTable: ✓ ✓ Use title block recognition ● ●
11.	Rotation for Landscape – allows for the setting of a rotation for Landscape documents.	Name: 9x12 No Border FoldingTable: Use title block recognition Image: Second
12.	Minimum width or short edge Maximum width or short edge Minimum Length or long edge Maximum Length or long edge Note: This configures the Minimum & Maximum for X&Y so that the software knows what size the drawing is and what roll size/fold packet/alignment/rotation/snap length/inter-copy delay are applied.	Neme: 9:12 lio Border I Use title block recognition 30' 9:0x12 Top right Right No Rotation 270' 34:50' 34:50' 30' 9:0x12



13.	 Snap to Cut Length - Add blank paper to the trailing edge of the copy. Note: For this example this setting is not used. 	Name: 9x12 No Border FoldingTable: Use title Block recognition 36° 9.0x12 Top right Right No Rotation 270° 34.50° 34.50° 1500.00° 0 0
14.	 Inter Copy Delay - in tenth of a second for fast printers or when tab applicator option is used. Note: For this example this setting is not used. 	Name: 9x12 No Border FoldingTable: ✓ ✓ Use title block recognition Ødf ✓ Ødf ✓
15.	Reset, Save, Save (activated) – If the settings are not correct select "Reset" to start over. Select "Save" to save the settings. Select "Save (activated)" to save the settings and have them be active and available for use.	Reset [Save [Save (activated)
16.	New Fold Preset – the new fold Preset will now be displayed in the left hand column under Custom.	□ Custom (1 item) Name Folding Enabled Legend Position Enabled ☑ 9x12 No Border On On ☑ 9x12 No Border On On ☑ 9x12 No Border On On ☑ 9x12 No Border On Un ☑ 9x12 No Border On On ☑ System (1 item) Image: System (1 item) Image: System (1 item) ☑ Name Folding Enabled Legend Position Enabled ☑ No folding Off Off

KIPFold 1800 User Guide

i 🕑 🞯 🚫 🔹 i tings Home Basic A	idvanced Preferences	Print Pro	\cap	0 - ×
Select All Select None Invert Selection	Color Color <th< th=""><th>% 100 % 141.4 % 150 % 200 % Bond</th><th>No Stamp</th><th>Auto Auto Enable Disable</th></th<>	% 100 % 141.4 % 150 % 200 % Bond	No Stamp	Auto Auto Enable Disable
ob Creator Job Queue Job	History		Auto Chn	•
A EMHT34663.pdf P\New A EMHT34664.pdf P\New A EMHT34665.pdf P\New A EMHT34666.pdf P\New A EMHT34667.pdf P\New A EMHT34668.pdf P\New	Aton/XIP Demo Files\ 0.5 MB 1/1 36.00° x 22.19° 22.19° x 36.00° Aton/XIP Demo Files\ 0.8 MB 1/1 36.00° x 22.28° 22.28° x 36.00° Aton/XIP Demo Files\ 0.6 MB 1/1 36.00° x 22.21° 22.21° x 36.00° Aton/XIP Demo Files\ 0.6 MB 1/1 36.00° x 22.21° 22.21° x 36.00° Aton/XIP Demo Files\ 0.5 MB 1/1 36.00° x 22.19° 22.19° x 36.00°	1x1 ♣ A CAD (Line) 100 % Bond 1x1 ♣ A CAD (Line) 100 % Bond 1x1 ♣ A CAD (Line) 100 % Bond 1x1 ♣ A CAD (Line) 100 % Bond	Auto 35 No Sti Auto JPN1 6 No Sti Auto JPN2 6 No Sti Auto USA 6 No Sti Arch-D	Script Algoment 🔛 🗋 ult 한: A 💭 O ult 한: A 💭 O ult 한: A 💭 O ult 한: A 💭 O ult 한: A 🏠 O ult 한: A 🏠 O
Method 2	Selected File – The folding column will display the selected Fold Pattern being applied.	Carlos Mercude Prot Guelly 0	The last of the la	Sarigs - Bucker

Folder Preset Selection


Method 1

In this method the fold packet to be used will be selected first by clicking the Fold button in the Basic tab ribbon bar. Once here select the desired Folder Packet setting to be applied to the entire job. Doing this procedure prior to selecting the files to be printed will then apply the selected fold packet to all selected files making everything in the job ticket print and fold the same way.

KIPFold 1800 User Guide

Method 2

In this method files will be added to the job ticket in the usual manner Home tab, (Add Files, Browse for and select files, add them to the job to be printed). Once the files to be printed have been added, go to the Basic tab and using the dropdown menu in the Fold column, each file can be given a different fold packet. This method can be used when a job has to be folded in a very specific way.





KIP PrintPro.Net and Folding

Folder Preset Creation

Cc	omponent	Functio	on
1.	System Preset Setup	⊘ Syste	tem Preset Setup
			Print Quality Presets Edit Print Quality Presets.
			Scan Quality Presets Edit Scan Quality Presets.
			Asc Stamp Presets Edit Stamp Presets.
			Page Sizes Edit Pagrilizes. Machine Notification Edit Machine Hotification.
			Job Notification Edit Job Notification.
l			Ps Presots Edit Ps Presots. Media Manager Edit Ps Presots.
l			
		-	ate setup has many functions within this section. These are explained lually here.
Step	Action		Illustration
1	Select the Folding Presets from the Printer Information page.		Folding Presets Edit Folding Presets.
2.	Select the New Button		le New
3.	Name – This is the name the displayed in the Preset names and will be display the main screen.	list of	Name: 9x12 No Border
4.	Use Title Block Recognitio	n –	
	Checking this box enables		FoldingTable:
	Title Block Recognition/Loo	cation.	Use title block recognition



Step	Action	Illustration
	Folding Table – This area is	
	where all settings for the Fold	
	Parameters are made.	
		1 2 3 4 5 6 7 8 9 10 11 12
	The Folding Table Icon Explained:	
	1. Media Width	
	2. Fold Packet	
	3. Title Block Location (Used w	hen Title Block Recognition is checked)
	 Alignment – Used to shift th paper size. 	e image Left, Centre, Right when the image is smaller than the
	5. Rotation – For Portrait View	,
	6. Rotation – For Landscape Vi	ew
	7. Minimum Width / Short Edg	ge (see note)
	8. Maximum Width / Short Edg	ge (see note)
	9. Minimum Length/ long Edge	e (see note)
	10. Maximum Length / Long	Edge (see note)
	11. Snap to Cut Length – Ade	d blank paper to the trailing edge of the copy.
		th of a second for fast printers or when tab applicator option is
	used. Note: For #'s 7, 8 9, 10 – This conf	igures the Minimum & Maximum for X&Y so that the software
	knows what size the drawing is ar	nd what roll size/fold packet/alignment/rotation/snap
	length/inter-copy delay are applie	ed.



Step	Action	Illustration
1.	Media Width – Select the desired Media Width to be used.	Name: 9x12 No Border FoldingTable: Use title block recognition 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5
2.	Fold Packet – Allows for the selection of the fold packet to be used.	Name: 9/12 No Border FoldingTable: Image: Control of the second seco
3.	Title Block Location – Allows for the selection of the title block Location. Note: when Use title block recognition is selected it is necessary to indicate where you want the title block to be.	Name: 9:12 No Border Folding Table: Use the block recognition 6 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0




4.	Alignment – Allows for the selection	
	of Left, Right or Centre for alignment.	Name: 0x12 No Border FoldingTable: Image: 0x12 No Border Image: 0x12 No B
		▶ 36* 9.0x12 Top right to No Rotation 270* 0.00* 0.00* 0.00* 0.00* 0 0 1eft 0 0 0 0 0 0 0 0 0 0 0 0 0
Step	Action	Illustration
1.	Rotation for Portrait – allows for the setting of a rotation for Portrait documents.	Name: 9x12 No Border FoldingTable:
	uocuments.	eff C C C C R Ba
2.	Rotation for Landscape – allows for	Name: 9x12 No Border
	the setting of a rotation for Landscape documents.	FoldingTable:
	uocuments.	eff 10
3.	Minimum width or short edge	
	Maximum width or short edge	Name: 9x12 No Border
	Minimum Length or long edge	Vestille block recognition
	Maximum Length or long edge	36" 9.0x12 Top right Right No Rotation 270" 34.50" 36.50" 34.50" 1.500.00" 0
	Note: This configures the Minimum & Maximum for X&Y so that the software	
	knows what size the drawing is and	
	what roll size/fold	
	packet/alignment/rotation/snap length/inter-copy delay are applied.	



4.	 Snap to Cut Length - Add blank paper to the trailing edge of the copy. Note: For this example this setting is not used. Inter Copy Delay - in tenth of a second 	Name: 9x12 No Border FoldingTable: Vust title block recognition 64 7 36 9.0x12 Top right Right No Rotation 270* 34.50* 36.50* 34.50* 36.50* 34.50* 1.50000* 0 Name: 9x12 No Border
	for fast printers or when tab applicator option is used. Note: For this example this setting is not used.	FoldingTable: Image: Control of the second sec
6.	Reset, Save, Save (activated) – If the settings are not correct select "Reset" to start over. Select "Save" to save the settings. Select "Save (activated)" to save the settings and have them be active and available for use.	🗟 Reset 🛛 🔚 Save 🔚 Save (activated)
7.	New Fold Preset – the new fold Preset will now be displayed in the left hand column under Custom.	□ Custom (1 item) Image: Name Folding Enabled Legend Position Enabled Image: System (1 item) On Image: Name Folding Enabled Legend Position Enabled Image: Name Folding Enabled Legend Position Enabled Image: No folding Off Off
8.	Folding from KIP ImagePro – Once the Folding Preset has been created and saved as active it can be selected and applied to jobs. Select the drop down arrow in the Folding button and pick the 9x12 No Border that was just created.	9x12 No Border • Folding

No part of this publication may be copied, reproduced or distributed in any form without express written permission from KIP. [©] KIP. All references subject to change without notice





Folder Preset Creation

In PrintPro.Net there are two methods for printing and selecting fold presets using the KIPFold 1800.

Method 1

In this method the fold packet to be used will be selected first by clicking the Fold button in the Basic tab ribbon bar. Once here select the desired Folder Packet setting to be applied to the entire job. Doing this procedure prior to selecting the files to be printed will then apply the selected fold packet to all selected files making everything in the job ticket print and fold the same way.

Gen Proceer ()
Gin Preser 🔝 🚦
PARTOWN OF SUC
On Printer (C)
La La
(In Printer 🔯 🖪
On Printer 🔯 🚦

KIPFold 1800 User Guide

Method 2

In this method files will be added to the job ticket in the usual manner Home tab, (Add Files, Browse for and select files, add them to the job to be printed). Once the files to be printed have been added, go to the Basic tab and using the dropdown menu in the Fold column, each file can be given a different fold packet. This method can be used when a job has to be folded in a very specific way.


	iii	BASIC SORT	4 files (1 pag	jes selected)	•	5	0	-Q-	41		0	1				- 1	Servic	ce -
wert.	Selec	Mirro	r 🖕 Rot Manipulate	ate 🗸	Color	PrintQ S	caling 🖕	1000	Starno	Fold	· ·	Hogi	 	xit Tra Avoid	, Ren	nov			
rint 🛛	٥	File Name	File Size	No.	Original Size		Copies	0	8	я і я	9	Q CAD	±6	C	0	ß		0	
		EMHT34665.pdf	0.8 MB		36' × 22.28'		1 x 1	Bond	100.0 %	1942	9	(Line) CAD	amp Aut			Default	On Printer		
	A	EMHT34665.pdf EMHT34667.pdf	0.6 MB		36' x 22.21' 36' x 22.19'			Bond	100.0 %		9	(Line) CAD	amp Auto			Default	On Printer		0
		EMHT34668.pdf	0.9 MB		36° x 22.19°			Bond	100.0 %		9	(Line) CAD (Line)	amp Aut				On Printer		0



KIP Windows Driver and Folding

When using the KIP Windows Driver to print and fold files follow these steps:

- 1. Select the file to be printed in the appropriate application. For this example Adobe is being used.
- 2. Go to File and select Print
- When the Print window opens select the installed KIP Windows Driver and then select the Properties button.
- 4. When the Properties button opens select the finishing button.



- 5. Under Finishing use the pull down to select one of the available Presets
- 6. Select the Desired Fold Packet.

Image: Construction of the second of the	AEDIA	PAGE SIZE	COPIES	QUALITY	LOG IN	
Addh-O Addh-O MECA Auto USA P 9 x 12 OH Defoult Disoble OURCE C(85 x 11) STAMP SEND TO Paper : 33.11° W 88 C 9 y 12 Disoble Disoble Disoble MAGE SCALE MAROR NVERT Paper : 17.00° Disable 100 % Sisable OF Disable Paper : 17.00°				Graphics (Line)	SNewon	*
OURCE Class 11 Ball Class 11 Ball Class 11 Composition Class 11 Ball Class 11 Composition Class 11 Compositio	Auto USA	Arch=0 p=7 85x11 p=7 9 x 12	8	0	-	Paper: 33.11"
Disable 10 % Construction Disable	and the two	L-(85x11 L-(9x12 L-99x12	e	Ne thomp	E Default	6888
	- 1	and a second second			491	Paper: 17.00"



KIP AutoCAD and Folding

When using the KIP AutoCAD Driver to print and fold files follow these steps:

- 1. From within AutoCAD go to File and then print.
- 2. Double click the installed KIP AutoCAD driver.


Page selup					Plot style table	Plot style table (pen assignments)	
Ngme:	diane>	•	Add _u .	meneda	🚮 monocirome Star.ctb (missa 🔹 🕎		
Printer/plot	ter				Shaded viewoo	rt options	
Name:	O None		•	hoperses	Shade plot	Legacy hidden	
Plotter: Plott			1				
	DWG To PDF pc3	-		DPS:			
Descrytion: Brudein followeb PR3.pc3 Plotin followeb PR3.pc3 Plotin file Publish To Web PR3.pc3 *					Plot options		
Plotto	jie per rubian to vieto riva pca				Plot in bed	toground	
Paper size Number of copies					Plot object lineweights Plot gransparency		
Previous paper size (11.00 x 17.00 Inches)							
			-		Plot with p		
Plot area		Plot sc	ale		Plot paper		
What to pi		Fit	Fit to paper			rspace objects	
Window • Window <		Scale:	Scale: Dustom +			Plot starp og Save changes to lavout	
	Plot offiet (origin set to printable area)		1	inches 💌 🛎	Drawing orient	-	
Plot officet			1.697	inta.	O Portrait		
Plot offict	2640 Inches 🕼 Center the plot				Landscape Plot upsde_down		

- 3. This will open the Plotter Configuration Editor
- 4. Select the Device and Document Settings Tab
- 5. Select the Custom Properties option
- 6. Select the Custom Properties button

Plotter Configuration Editor - KIP Color Systems.pc3 General Ports Device and Document Settings KIP Color Systems.pc3 8-0 Media Source and Size <Src: Rdl><Width: _><Size: ANSI C (17 x 22 Ir Graphics ÷ Custom Properties User-defined Paper Sizes & Calibration E A Custom Paper Sizes Modify Standard Paper Sizes (Printable Area) Filter Paper Sizes Plotter Calibration PMP File Name (None) 1 111 Access Custom Dialog Press the following button to access the device driver-specific user-interface. Custom Properties. Save As... Import ... Defaults OK Help Cancel



- Once the custom properties window opens under Media Options select the Folder Button.
- Select any of the available presets to apply that setting to the files being printed.



- 9. Select OK to set this
- 10. Select OK again to return to the print screen and submit the file.

Media Type:	
	Bond
Alignment:	Default
Remove borders:	None
Folder:	A0 DIN-8
Ext Tray:	Default
Adjustments Quality Preset:	
Quality Preset:	
HPGL Preset:	
Color Adjustment	



Troubleshooting

In case an issue occurs, an error code will be shown on the tablet screen


This could be a open cover or a paper jam

If there is remaining paper pinched between fold rollers or other turning parts close the covers and press the purge button 2. All transport belts and rollers will be switched on until you press the button again.

After taking out the jammed paper or closing the cover, the folder needs to be restarted by clicking on the exit button (3)

The folder will reboot now and check the paper path again. This takes approx. 20 seconds. Thereafter, the folder will be ready.

The "key" button (1) gives the technician the possibility to enter the service menu.





How To clean start-up errors 22:xx / 82:xx

After a start-up error has occurred you have to make sure that no paper is still located inside the machine.


Such errors could be for example:

- 22:xx for Fan Folder start-up errors
- 82:xx for Cross Folder start-up errors

Always use the purge function before you remove any paper remains by hand.

In case of Fan Folder errors open the red highlighted cover (2) and remove every piece of paper between the fold rollers and from the paper path. Close the cover.


In case of Cross Folder errors open cover (1) and remove every piece of paper between the transport belts, inside the Tilt Tray and below it. Close the cover. Also lift the fan unit (3) and remove the paper under it.






How to purge

- Do not open the bridge and do not remove the prints manually
- Use purge every time at first



- On the screen of the folder, there is an error message with "Sensor S-XX cut".
- The purge function is placed at the upper right corner.



- Press and hold the purge button!
- If the cleaning phase is passed, you can stop to hold its.
- Finally check the folder. It should be empty of any packages.

KIPFold 1800 User Guide

KIP IS COMMITTED TO PRODUCT DESIGNS THAT PROMOTE ENVIRONMENTAL HEALTH AND SUSTAINABILITY. OUR GOAL IS TO CONSISTENTLY IMPROVE AND REFINE THE TECHNOLOGIES IN KIP PRODUCTS THAT KEEP OUR PLANET GREEN.

The greatest environmental benefit of KIP products is through the actual operation of our products and solutions. We improve the customer experience by integrating environmental considerations into our business strategy – resulting in superior products.

LEARN

Customers increasingly value environmental aspects of products. such as energy efficiency, emissions reduction and the ability to recycle exhausted supply containers. We differentiate our products by integrating such features to deliver o low total cost of ownership and on improved user experience.

• Energy Star Qualified • ROHS Compliancy • ISO 14001 Standards

• Ozone Emissions Filters • UL/UL-C Approved • 100% Toner Efficiency – No Waste Toner • Organic, Recyclable Photoreceptors • Recyclable Toner Containers • Prints on Recycled Paper • Automatic Image Rotation and Media Selection Ensure Minimal Paper Waste



ENVIRONMENTAL RESPONSIBILITY

